SIEMENS


A5W02664000


SID


Programmable Room Thermostat RDL211/H




cs	Návod k montáži
da	Monteringsvejledning
de	Montageanleitung
el	Οδηγίες τοποθέτησης
en	Mounting instructions
es	Instrucciones de montaje
et	Paigaldusjuhised
fi	Asennusohjeet
fr	Instructions de montage
hu	Telepítési leírás
it	Istruzioni di montaggio
lt	Montavimo instrukcijos
lv	Montāžas instrukcijas
nl	Montageaanwijzing
no	Monteringsinstruksjoner
pl	Instrukcja montażu
pt	Instruções de instalação
ro	Instructiuni de montaj
sk	Návod na montáž
sv	Monteringsinstruktion
tr	Montaj talimatlari
zh	安装指南












1




2




3




4




5




6





7



8








http://www.siemens.com/download?A6V16531087

On/off devices




P01	Y1	Y2
1 = HEATING		→ P50
2 = COOLING		→ P50
3 = HEAT/COOL	/	→ P50
4 = HEAT/COOL + CO	/	Chovr
5 = HEAT + COOL		

P04
1 = ON/OFF


⚠ Lx – Nx AC 24...230 V

Reversible heat pump



P01
4 = HEAT/COOL + CO


Heat pump (reversible/non-reversible) or boiler



P01
1 = HEATING
5 = HEAT + COOL

P04
1 = ON/OFF

3-position valve actuator



P01
1 = HEATING
2 = COOLING
3 = HEAT/COOL

P04
2 = 3-POSITION

⚠ Lx – Nx AC 24...230 V

Mobile app

Quick Config



Issued by
Siemens Switzerland Ltd
Smart Infrastructure
Global Headauarters
Theilerstrasse 1a
CH-6300 Zug
Tel. +41 58 724 2424
www.siemens.com/buildingtechnologies

Open Source Software (OSS)

All open source software components used within the product (including their copyright holders and the license conditions) can be found from the website https://www.siemens.com/download?A6V13482237.

© Siemens Switzerland Ltd., 2025
Technical specifications and availability subject to change without notice.